
Glass-Lined Thermal Carafe

1.25 Liter / 10 Cup / 40 Ounce



Heat-Retaining Glass Lining

The borosilicate glass lining retains heat and keeps your coffee hotter longer.

High-Quality, Durable Materials

Our thermal carafe features a stainless steel exterior, borosilicate glass liner, and BPA/BPS/BPF- and phthalate-free plastics.

Brew-Thru Lid

The Brew-Thru Lid allows coffee to drip directly into the carafe, minimizing heat loss while brewing. You can pour your coffee through the Brew-Thru Lid without loosening or removing it.

Ready for Travel

The leak-proof travel lid keeps the carafe closed tightly while on the go.

Brewer Compatible

Our glass-lined thermal carafe is compatible with all 40 oz thermal brewer models, including the KBT, KBGT, and CDGT.

The glass liner is not replaceable. Do not remove the bottom of the carafe.

www.moccamaster.com

IMPORTANT SAFEGUARDS

- Check that the screw-on base is firmly in place before using the carafe for the first time and, if necessary, screw it tight to guarantee that it is ideally sealed.
- Prevent glass breakage: Rinse the carafe with warm water just before filling it with hot beverages, or with cold water if the contents are to be kept cooled. Avoid sudden and extreme temperature differences.
- In the case of glass breakage, do not drink the contents.
- Do not unscrew and remove the bottom of the carafe. Glass liner is not replaceable.
- Never hold your face directly over the opening when filling the carafe.
- Never place thermal carafe on a stovetop, gas cooker, or other heat source.
- Never place carafe in an oven or a microwave.
- WARNING: Do not drink directly from thermal carafe. Liquid from carafe may be very hot.

- Incorrect handling can lead to damage and, at worst, injury.
- Do not use for carbonated beverages.
- Do not leave unattended in the hands of children.
- Do not use thermal carafe for storing dairy products or baby food, as these will curdle if kept hot for a longer period of time.
- Do not transport carafe in a horizontal or upside-down position, as it can lead to leakage. Use special travel lid for transporting.
- Do not use metal items for stirring, and do not add ice cubes.
- Do not clean carafe with abrasive cleansers, steel wool pads, or similar materials.
- Do not put the carafe in the dishwasher or submerge it in washing water.
- NOT DISHWASHER SAFE.